



| Original | | Sustituto | | Original | | Sustituto | |
|----------|------------------|-----------|--------------|----------|-------------|-----------|----------------|
| | Power | | Power | | Fav | | Shift + Pre Ch |
| | Mute | | Mute | | Size | | Eject |
| | 1 | | 1 | | Vol+ | | Vol + |
| | 2 | | 2 | | Vol- | | Vol - |
| | 3 | | 3 | | CH+ / Page+ | | Ch + |
| | 4 | | 4 | | CH- / Page- | | Ch - |
| | 5 | | 5 | | QV Top | | Smart |
| | 6 | | 6 | | Source | | AV |
| | 7 | | 7 | | Menu | | Menu |
| | 8 | | 8 | | Q.Menu | | D. Menu |
| | 9 | | 9 | | Display | | Info |
| | 0 | | 0 | | Up | | Up |
| | Audio Lang. I/II | | Dual | | Left | | Left |
| | Subtl | | Subt | | OK | | Ok |
| | EPG | | Guide | | Right | | Right |
| | -> P <- | | Format | | Down | | Down |
| | -> S <- | | Shift + Dual | | Exit | | Exit |



