



| Original | Sustituto         |
|----------|-------------------|
|          | Mute / Dimmer     |
|          | Power             |
|          | TV/Radio /        |
|          | Audio / Lang I/II |
|          | Sound / Title     |
|          | Back / Return     |
|          | 1                 |
|          | 2                 |
|          | 3                 |
|          | 4                 |
|          | 5                 |
|          | 6                 |
|          | 7                 |
|          | 8                 |
|          | 9                 |
|          | 0                 |
|          | Guide / EPG / --  |

| Original | Sustituto                   |
|----------|-----------------------------|
|          | Smart / List                |
|          | Up                          |
|          | CH+ / Page+                 |
|          | Right                       |
|          | Vol+                        |
|          | Left                        |
|          | Vol-                        |
|          | OK                          |
|          | Down                        |
|          | CH- / Page-                 |
|          | Red / Netflix / Search      |
|          | Green / APP / Repeat        |
|          | Shift + Audio / Lang I/II   |
|          | Yellow / YouTube / Repeat   |
|          | Blue / Prime Video / Random |
|          | Display / Media             |
|          | Stop / Hold                 |



