


































Original	Sustituto
 Power	 Power
 Mute	 Mute / Dimmer
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 3D Sound	 Sound / Title
 Dolby PL II	 Audio / Lang I/II
 S/W Level	 Subtitle / EQ
 Eject	 Eject / Surround
 Full Screen	 Zoom / Size
 Sleep	 Sleep / Timer
 Function	 TV/Radio /
 Disc Menu	 D.Menu / Top

Original	Sustituto
 Tools	 Setup / OPT /
 vTuner	 Text / Goto
 Menu	 Menu / Home
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Return	 Back / Return
 Vol +	 Vol+
 Smart Hub	 Smart / List
 Tuning / CH +	 CH+ / Page+
 Vol -	 Vol-
 DSP	 Display / Media
 Tuning / CH -	 CH- / Page-







































Original	Sustituto
1 / RDS Display	1
2	2
3 / TA	3
4 / PTY -	4
5 / PTY Search	5
6 / PTY +	6
7	7
8	8
9	9
SFE Mode	Guide / EPG / -/--
0	0
2D → 3D	Fav / Marker / PC
Red	Red / Netflix / Search
Green / iPod Sync	Green / APP / Repeat
Yellow / Tuner Memory	Yellow / YouTube / Repeat
Blue / Mo/St	Blue / Prime Video / Random
Title Menu / PopUp Menu	Shift + Home Menu / Home

Original	Sustituto
Search	Shift + Red / Netflix /
Repeat	Shift + Green / APP /





Original	Sustituto
 Power	 Power
 TV Source	 AV / Input / RDS
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+

Original	Sustituto
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 Vol-	 Vol-
 CH-	 CH- / Page-
 Menu	 Menu / Home
 Tools	 Setup / OPT /
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down





Original	Sustituto
Exit	Exit / Cancel / Clear
Red	Red / Netflix / Search
Green/iPod	Green / APP / Repeat
Yellow/Tuner	Yellow / YouTube / Repeat
Blue/Mo/St	Blue / Prime Video / Random
Smart HUB	Smart / List
Search	Shift + Red / Netflix /
2D-3D	Audio / Lang I/II

Original	Sustituto

