






































| Original   | Sustituto  |
|--|--|
|  Open / Close |  Eject / Surround     |
|  Mute         |  Mute / Dimmer        |
|  NP           |  D.Menu / Top         |
|  Recall       |  Back / Return        |
|  PS           |  Text / Goto          |
|  Spectrum     |  Smart / List         |
|  1            |  1                    |
|  2            |  2                    |
|  3            |  3                    |
|  4            |  4                    |
|  5           |  5                   |
|  6          |  6                  |
|  7          |  7                  |
|  8          |  8                  |
|  9          |  9                  |
|  0          |  0                  |
|  +10        |  Guide / EPG / -/-- |

| Original   | Sustituto  |
|--|--|
|  Clear      |  Exit / Cancel / Clear  |
|  Stop       |  Stop / Hold            |
|  Zoom       |  Zoom / Size            |
|  3D         |  Picture / Format       |
|  Search     |  Red / Netflix / Search |
|  Play       |  Play / Slow            |
|  Pause      |  Pause / Step / Freeze  |
|  Setup      |  Setup / OPT /          |
|  L/R Audio  |  Audio / Lang I/II      |
|  Left       |  Left                   |
|  Up        |  Up                    |
|  Right    |  Right                |
|  Enter    |  OK                   |
|  Down     |  Down                 |
|  PBC Menu |  Menu / Home          |
|  Vol-     |  Vol-                 |
|  Vol+     |  Vol+                 |





| Original | Sustituto                 |
|----------|---------------------------|
| OSD      | Display / Media           |
| I<<      | I<< / Preset-             |
| >>I      | >>I / Preset+             |
| <<       | << / Tune-                |
| >>       | >> / Tune+                |
| Title    | Sound / Title             |
| Slow     | +  Shift + Play /         |
| Repeat   | Green / APP / Repeat      |
| A-B      | Yellow / YouTube / Repeat |
| Return   | +  Shift + Back / Return  |
| Subtitle | Subtitle / EQ             |
| Angle    | Info / Angle              |
| Prog     | TV/Radio /                |
|          |                           |
|          |                           |
|          |                           |
|          |                           |

| Original | Sustituto |
|----------|-----------|
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |

