



























































Original	Sustituto		
	Power		Power
	TV		TV/Radio /
	Radio		Shift + TV/Radio / Program
	Subtitle		Subtitle / EQ
	ALT		Smart / List
	ARC		Display / Media
	TV Guide		Guide / EPG / -/--
	Mute		Mute / Dimmer
	Language		Audio / Lang / I/II
	PG		Sound / Title
	Info		Info / Angle
	Exit		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down

Original	Sustituto		
	P+		CH+ / Page+
	V+		Vol+
	P-		CH- / Page-
	V-		Vol-
	Red		Red / Netflix / Search
	White		Fav / Marker / PC
	Green		Green / APP / Repeat
	Blue		Blue / Prime Video / Random
	Yellow		Yellow / YouTube / Repeat
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8









































































Original		Sustituto		Original		Sustituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				






Original		Sustituto		Original		Sustituto	
	Power		Power		P+		CH+ / Page+
	TV		TV/Radio /		V+		Vol+
	Radio		Shift + TV/Radio / Program		P-		CH- / Page-
	Subtitle		Subtitle / EQ		V-		Vol-
	ALT		Smart / List		Red		Red / Netflix / Search
	ARC		Display / Media		White		Fav / Marker / PC
	TV Guide		Guide / EPG / -/--		Green		Green / APP / Repeat
	Mute		Mute / Dimmer		Blue		Blue / Prime Video / Random
	Language		Audio / Lang / I/II		Yellow		Yellow / YouTube / Repeat
	PG		Sound / Title		1		1
	Info		Info / Angle		2		2
	Exit		Exit / Cancel / Clear		3		3
	Up		Up		4		4
	Left		Left		5		5
	OK		OK		6		6
	Right		Right		7		7
	Down		Down		8		8









































































Original		Sustituto		Original		Sustituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				













Original	Sustituto	Original	Sustituto
	Power		Power
	TV		TV/Radio /
	Radio		Shift + TV/Radio / Program
	Subtitle		Subtitle / EQ
	ALT		Smart / List
	ARC		Display / Media
	TV Guide		Guide / EPG / -/--
	Mute		Mute / Dimmer
	Language		Audio / Lang I/II
	PG		Sound / Title
	Info		Info / Angle
	Exit		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	P+		CH+ / Page+
	V+		Vol+
	P-		CH- / Page-
	V-		Vol-
	Red		Red / Netflix / Search
	White		Fav / Marker / PC
	Green		Green / APP / Repeat
	Blue		Blue / Prime Video / Random
	Yellow		Yellow / YouTube / Repeat
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8





























































Original		Sustituto		Original		Sustituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				





Original	Sustituto
 Power	 Power
 TV	 TV/Radio /
 Radio	 Shift + TV/Radio / Program
 Subtitle	 Subtitle / EQ
 ALT	 Smart / List
 ARC	 Display / Media
 TV Guide	 Guide / EPG / -/--
 Mute	 Mute / Dimmer
 Language	 Audio / Lang I/II
 PG	 Sound / Title
 Info	 Info / Angle
 Exit	 Exit / Cancel / Clear
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down

Original	Sustituto
 P+	 CH+ / Page+
 V+	 Vol+
 P-	 CH- / Page-
 V-	 Vol-
 Red	 Red / Netflix / Search
 White	 Fav / Marker / PC
 Green	 Green / APP / Repeat
 Blue	 Blue / Prime Video / Random
 Yellow	 Yellow / YouTube / Repeat
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





Original	Sustituto	Original	Sustituto
9	9		
Menu	Menu / Home		
Help	Text / Goto		
0	0		

