



Original	Sustituto	Original	Sustituto
Operate	Power	Tv Prog-	Ch -
1	1	Right	Right
2	2	Left	Left
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Tv/Video	TV/R		
Mute	Mute		
'I'	Dual		
Tv Vol+	Vol +		
Tv Vol-	Vol -		
Tv Prog+	Ch +		





Original	Sustituto	Original	Sustituto
	Operate		Power
	Store		Smart
	CH Set		Media
	Review		Guide
	Clock		Back
	C.Memory/Display		Info
	Mode		Format
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	C.Reset/Cancel		Exit
	Start+		Vol +
	Timer		AV
	Start-		Vol -
	Stop+		Up
	Stop-		Down
	Date+		Right
	Date-		Left
	Tv Prog+/Up		Ch +
	Tv Prog-/Down		Ch -
	'/'		Dual
	AudioMonitor		Mute
	Tv/Video		TV/R
	<<		Play
	Play		Play
	>>		Rec
	Rec		Rec









































































Original	Sustituto
 Stop	 Stop
 Pause	 Pause
 Scene Finder	 3D
 Prog/Check	 Menu
 Prog	 Sleep
 OK	 Ok
 >>I/Push Jog+	 >>I
 I<</Push Jog-	 I<<

Original	Sustituto







Original	Sustituto	Original	Sustituto
 Operate	 Power	 C.Reset/Cancel	 Exit
 Store	 Smart	 Timer	 AV
 CH Set	 Media	 Start+	 Vol +
 Review	 Guide	 Start-	 Vol -
 Clock	 Back	 Stop+	 Up
 C.Memory Display	 Info	 Stop-	 Down
 Mode	 Format	 Date+	 Right
 1	 1	 Date-	 Left
 2	 2	 Tv Prog+/Up	 Ch +
 3	 3	 Tv Prog-/Down	 Ch -
 4	 4	 TV	 Dual
 5	 5	 Audio/Monitor	 Mute
 6	 6	 Tv/Video	 TV/R
 7	 7	 <<	 <<
 8	 8	 Play	 Play
 9	 9	 >>	 >>
 0	 0	 Rec	 Rec





Original	Sustituto
 Stop	 Stop
 Pause	 Pause
 Scene Finder	 3D
 Prog Check	 Menu
 Prog	 Sleep
 OK	 Ok
 >> /Push Jog+	 >>
  <</Push Jog-	  <<

Original	Sustituto

