



Original	Sustituto	Original	Sustituto
 Power	 Power	 0	 0
 Open/Close	 Eject	 Return	 Back
 Band	 Red	 XTS Pro	 Media
 DVD	 Green	 Marker	 Format
 AUX	 Yellow	 Search	 TV/R
 USB	 Blue	 O)))/Audio	 Dual
 Sleep	 Sleep	 Sound	 Shift + Dual
 Dimmer	 D. Menu	 [...] / Subtitle	 Subt
 1	 1	 VSM	 Smart
 2	 2	 Setup	 Options
 3	 3	 Display	 Info
 4	 4	 Up	 Up
 5	 5	 Preset+	 Ch +
 6	 6	 Down	 Down
 7	 7	 Preset-	 Ch -
 8	 8	 Right/Tun.+	 Right
 9	 9	 Left/Tun-	 Left





Original	Sustituto	Original	Sustituto
Enter	Ok	Mute	Mute
Menu	Menu	RDS	AV
Title	List		
<</Scan-	<<		
>>/Scan+	>>		
Play	Play		
<</Skip-	<<		
>> /Skip+	>>		
Pause/Step	Pause		
Stop	Stop		
Repeat	Text		
Repeat A-B	Shift + Text		
Vol+	Vol +		
Vol-	Vol -		
Prog/Memo	Shift + Sleep		
Clear	Exit		
Zoom	Shift + Eject		

Original	Sustituto
Mute	Mute
RDS	AV

