







































































Original	Sustituto	Original	Sustituto
 Standby	 Power	 Right	 Right
 Display	 Shift + Info	 Down	 Down
 Nicam / Eject	 Eject	 Source	 AV
 Mute	 Mute	 Exit	 Exit
 P.Mode	 Shift + Format	 1	 1
 S.Mode	 Shift + Dual	 2	 2
 Sleep	 Sleep	 3	 3
 Aspect	 Format	 4	 4
 Vol -	 Vol -	 5	 5
 Vol +	 Vol +	 6	 6
 CH -	 Ch -	 7	 7
 CH +	 Ch +	 8	 8
 LCD-Menu	 Menu	 9	 9
 DVD-Setup	 Options	 0	 0
 Up	 Up	 Recall	 Back
 Left	 Left	 Text / Audio	 Text
 Enter	 Ok	 Hold / A-B / Rec List	 Smart





	Original	Sustituto	Original	Sustituto
	Rec	 Rec		 +  Shift + Pause
	Time Shift	 Media		 >>
	Red / Repeat	 Red		 Subt
	Red / Repeat	 +  Shift + Text		 Guide
	Green / Zoom	 Green		 Pre Ch
	Green / Zoom	 +  Shift + Eject		 +  Shift + Sleep
	Yellow / Angle	 Yellow		 Info
	Blue / Goto	 Blue		
	Index / I<<	 I<<		
	Size / Stop	 Stop		
	Rev. / Play/Pause	 Play		
	Rev. / Play/Pause	 Pause		
	Sub.P / >>I	 >>I		
	TV/Radio / <<	 <<		
	TV/Radio / <<	 TV/R		
	Lang / Menu	 Dual		
	Lang / Menu	 D. Menu		

