





































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Back		Back
	Vol +		Vol +
	Vol -		Vol -
	Nicam / A2		3D
	Sleep		Sleep
	CH +		Ch +
	CH -		Ch -
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Exit		Exit
	Mode		Media
	TV / Radio		TV/R
	Freeze		Pause
	Subtitle		Subt
	Text		Text
	P.Mode		Shift + Format
	S.Mode		Dual





Original	Sustituto
MIX	Smart
HOLD	Stop
INDEX	Shift + Info
SUBPAGE	AV
REVEAL	D. Menu
Red	Red
Green	Green
Size	Format
Yellow	Yellow
Blue	Blue
Zoom	Eject
Fav-CH	Pre Ch
EPG	Guide
CH List	List

Original	Sustituto

