







Original	Sustituto
Source	AV / Input / RDS
Power	Power
[...]	Subtitle / EQ
Audio	Audio / Lang I/II
Sync Menu	Shift + D.Menu / Top Menu
Related Search	Shift + Red / Netflix /
Tv Pause	Shift + Pause / Step /
<<<	<<< / Tune-
Play	Play / Slow
>>>	>>> / Tune+
Title List	Sound / Title
Rec	Rec / Rec Mode
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat

Original	Sustituto
Blue	Blue / Prime Video / Random
Social View	Picture / Format
Football	Fav / Marker / PC
SEN/APPS	Shift + Green / APP /
Discover	Display / Media
Guide	Guide / EPG / -/-
Up	Up
Left	Left
OK	OK
Right	Right
Return/Back	Back / Return
Down	Down
Options	Setup / OPT /
Home	Menu / Home
Digital/Analog	Smart / List
[i+]/[?]	Info / Angle
?/i-Manual	D.Menu / Top





Original	Sustituto
 Exit	 Exit / Cancel / Clear
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Tv/Radio	 TV/Radio /
 0	 0
 [=]/Text	 Text / Goto
 Mute	 Mute / Dimmer
 Vol+	 Vol+
 PR+	 CH+ / Page+
 Vol-	 Vol-

Original	Sustituto
 PR-	 CH- / Page-
 Recall	 Shift + Back / Return

