














































































| Original | Rechange | Original | Rechange |
|---|--|---|--|
|  Power |  Power |  Recall |  Back |
|  Nicam/Eject |  Eject |  Tv-Menu |  Menu |
|  Mute |  Mute |  Source |  AV |
|  Display |  Shift + Info |  DVD Setup |  Options |
|  Sleep |  Sleep |  Up |  Up |
|  Aspect |  Format |  Left |  Left |
|  1 |  1 |  Enter |  Ok |
|  2 |  2 |  Right |  Right |
|  3 |  3 |  Down |  Down |
|  4 |  4 |  Red/Repeat |  Red |
|  5 |  5 |  Green/Zoom |  Green |
|  6 |  6 |  Yellow/Angle |  Yellow |
|  7 |  7 |  Blue/Goto |  Blue |
|  8 |  8 |  Text/Audio |  Text |
|  9 |  9 |  Tv/Radio/Menu |  TV/R |
|  0 |  0 |  Exit |  Exit |
|  FAV |  Pre Ch |  P.Mode |  Shift + Format |





| Original | | Rechange | | Original | | Rechange | |
|---|-------------------|---|-------|---|------------|---|------|
|  | S.Mode |  | Dual |  | Info/Title |  | Info |
|  | Vol+ |  | Vol + | | | | |
|  | Vol- |  | Vol - | | | | |
|  | CH+ |  | Ch + | | | | |
|  | CH- |  | Ch - | | | | |
|  | I<</Index |  | I<< | | | | |
|  | Play/Reveal |  | Play | | | | |
|  | Pause |  | Pause | | | | |
|  | >>I/Subpage |  | >>I | | | | |
|  | << |  | << | | | | |
|  | Stop/Size |  | Stop | | | | |
|  | >> |  | >> | | | | |
|  | Hold/A-B/Rec List |  | List | | | | |
|  | Rec/Slow |  | Rec | | | | |
|  | Time Shift |  | Smart | | | | |
|  | EPG/Program |  | Guide | | | | |
|  | Subtitle |  | Subt | | | | |

