



Original	Recharge
Power	Power
Input	AV
Power Tv	Shift + Power
Input Tv	Shift + AV
Tv Vol+	Shift + Vol +
Tv Vol-	Shift + Vol -
Tv CH+	Shift + Ch +
Tv CH-	Shift + Ch -
Sound Field +	Ch +
Sound Field -	Ch -
STD	Options
Movie	Dual
Game	Media
Music	List
P.Audio	Smart
Stereo	Subt
Speaker/Tv↔Audi	TV/R

Original	Recharge
Display	Info
Return	Back
AMP Menu	Menu
Vol+	Vol +
Vol-	Vol -
Muting	Mute
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
I<<	I<<
Pause	Pause
>>I	>>I
<<	<<
Play	Play
>>	>>



