




Original	Recharge
Open / Close	Eject / Surround
Mute	Mute / Dimmer
NP	D.Menu / Top
Recall	Back / Return
PS	Text / Goto
Spectrum	Smart / List
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
+10	Guide / EPG / -/--

Original	Recharge
Clear	Exit / Cancel / Clear
Stop	Stop / Hold
Zoom	Zoom / Size
3D	Picture / Format
Search	Red / Netflix / Search
Play	Play / Slow
Pause	Pause / Step / Freeze
Setup	Setup / OPT /
L/R Audio	Audio / Lang I/II
Left	Left
Up	Up
Right	Right
Enter	OK
Down	Down
PBC Menu	Menu / Home
Vol-	Vol-
Vol+	Vol+





Original	Recharge
 OSD	 Display / Media
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 Title	 Sound / Title
 Slow	 Shift + Play /
 Repeat	 Green / APP / Repeat
 A-B	 Yellow / YouTube / Repeat
 Return	 Shift + Back / Return
 Subtitle	 Subtitle / EQ
 Angle	 Info / Angle
 Prog	 TV/Radio /

Original	Recharge

