



Original	Rechange
Power	Power
Tv/Rad	TV/R
Tv/PC	3D
Subtitle	Subt
*	Menu
Sources	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/Quick Access/*	0
List	List

Original	Rechange
.../*	Format
FAV	Pre Ch
Guide	Guide
Vol+	Vol +
Vol-	Vol -
Mute	Mute
CH+	Ch +
CH-	Ch -
Text	Text
Home	Smart
T.Opt	Options
Back	Back
Exit	Exit
AD/*/PIP/*	Dual
Q.Menu/*	D. Menu
Up	Up
Down	Down



