


























































Original	Rechange
 Standby	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Display	 Info
 Picture	 Shift + Format
 Sleep	 Sleep
 Mode	 Smart

Original	Rechange
 Return	 Back
 Up	 Up
 Left	 Left
 Menu	 Menu
 Menu	 Ok
 Right	 Right
 Down	 Down
 Mute	 Mute
 Zoom	 Eject
 Nicam/A2	 Dual
 Sound	 Shift + Dual
 Text	 Text
 Cancel	 Exit
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Cyan	 Blue





Original		Recharge	
	Mix		Shift + Text
	Size		Format
	Hold		Stop
	Reveal		Media
	Index		Options
	Subpage		Subt
	Up		Ch +
	Down		Ch -
	Left		Vol -
	Right		Vol +

Original		Recharge	

