



Original	Replacement
	Power
	Source
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TTX/MIX
	PRE-CH
	Vol +
	Vol -
	Mute

Original	Replacement
	CH LIST
	P+
	P-
	Content
	Menu
	Guide
	Tools
	Info
	Up
	Right
	Down
	Left
	OK
	Return
	Exit
	Red/A
	Green/B





Original		Replacement		Original	Replacement
	Yellow/C		Yellow		
	Blue/D		Blue		
	E-Manual		D. Menu		
	P.Size		Format		
	AD/Subt		Subt		
	Stop		Stop		
	I<<		I<<		
	<<		<<		
	Play		Play		
	Pause		Pause		
	>>		>>		
	>>I		>>I		

