



















| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-------------|
| | Power | | Power |
| | Mute | | Mute |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | OK/Select | | Ok |
| | M | | Menu |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | -/-- | | Guide |
| | Exit | | Exit |
| | P<P/Swap | | Pre Ch |
| | Vol+ | | Vol + |
| | Vol- | | Vol - |
| | P+ | | Ch + |
| | P- | | Ch - |
| | PP | | Eject |
| | I-II | | Dual |
| | Tv/DTV | | TV/R |
| | [≡] | | Text |
| | [≡0] | | Options |
| | AV/Source | | AV |
| | [≡+]/[X] | | Format |
| | [≡X]/[■] | | 3D |
| | [.≡]/[■] | | Subt |





| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  [≡♦] |  Media | | |
|  [≡?] |  Back | | |
|  [≡i] |  Info | | |
|  Red/[+]/Wide/↑ |  Red | | |
|  Green/↓ |  Green | | |
|  Yellow |  Yellow | | |
|  Blue/Guide |  Blue | | |
|  [i] |  D. Menu | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

