



| Original | | Replacement | | Original | | Replacement | |
|----------|----------|-------------|-----------------------------|----------|----------|-------------|-----------------------|
| | Power | | Power | | 7 | | 7 |
| | Screen | | Picture / Format | | 8 | | 8 |
| | Lang | | Audio / Lang I/II | | [≡]/Text | | Text / Goto |
| | Subtitle | | Subtitle / EQ | | 9 | | 9 |
| | www | | Smart / List | | 0 | | 0 |
| | Red/▲ | | Red / Netflix / Search | | Recall | | Back / Return |
| | Red/▲ | | Shift + CH+ / | | Up | | Up |
| | Green/▼ | | Green / APP / Repeat | | Menu | | Menu / Home |
| | Green/▼ | | Shift + CH- / | | Left | | Left |
| | Yellow | | Yellow / YouTube / Repeat | | Right | | Right |
| | Blue | | Blue / Prime Video / Random | | Return | | Shift + Back / Return |
| | 1 | | 1 | | Down | | Down |
| | 2 | | 2 | | OK | | OK |
| | 3 | | 3 | | Source | | AV / Input / RDS |
| | 4 | | 4 | | FAV | | Fav / Marker / PC |
| | 5 | | 5 | | Presets | | Setup / OPT / |
| | 6 | | 6 | | Sleep | | Sleep / Timer |



