






































































Original	Replacement	Original	Replacement
	Power		Power
	Menu		Red
	3D		Green
	TV Input		Yellow
	AV Input		Blue
	i		Mute
	Exit		Mute
	APPS		Text
	Home		Text
	Guide		STTL
	Up		STTL
	Down		[+]/Aspect
	Right		Vol+
	Left		Vol-
	OK		CH+
	Option		CH-
	Return/Back		1
			2
			3
			4
			5





	Original	Replacement	Original	Replacement
	6			
	7			
	8			
	9			
	0			
	?/Help			
	Last View			
	<<			
	Play			
	>>			
	I<<			
	Pause			
	>>I			
	Stop			
	Rec	