







































































Original	Replacement	Original	Replacement
 Power	 Power	 Rec	 Rec
 Input	 AV	 CH +	 Ch +
 Mute	 Mute	 CH -	 Ch -
 1	 1	 Vol +	 Vol +
 2	 2	 Vol -	 Vol -
 3	 3	 FAV	 Pre Ch
 4	 4	 OK	 Ok
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 EPG	 Guide
 0	 0	 Info	 Info
 Return	 Back	 Goto/PlayList	 Options
 Menu	 Menu	 ECO/TFT Off	 Media
 Exit	 Exit	 Play	 Play
 [:≡]	 Smart	 Pause/TS	 Pause





Original	Replacement	Original	Replacement
 Stop/Reveal	 Stop		
 Repeat/TV/TXT	 Text		
 I<</Hold	 I<<		
 >>I/Subpage	 >>I		
 <</Index	 <<		
 >>/Cancel	 >>		
 Red	 Red		
 Subtitle	 Subt		
 Green	 Green		
 Audio	 Dual		
 Yellow	 Yellow		
 16:9	 Format		
 Blue	 Blue		
 Sleep	 Sleep		

