



| Original  | Replacement | Original  | Replacement       |
|---|-------------|---|-------------------|
|      | Power       |      | Power             |
|      | Mute        |      | Mute / Dimmer     |
|      | Hold        |      | Stop / Hold       |
|      | ♪           |      | Sound / Title     |
|      | Sub         |      | Subtitle / EQ     |
|      | 16:9        |      | Picture / Format  |
|      | TV/TX       |      | TV/Radio /        |
|      | Double      |      | D.Menu / Top      |
|      | [ ]         |      | Setup / OPT /     |
|      | Mix         |      | Text / Goto       |
|     | AV          |     | AV / Input / RDS  |
|    | Menu        |    | Menu / Home       |
|    | Up          |    | Up                |
|    | Left        |    | Left              |
|    | OK          |    | OK                |
|    | Right       |    | Right             |
|    | Down        |    | Down              |
|    | Swap        |    | Back / Return     |
|    | Vol+        |    | Vol+              |
|    | PP          |    | Smart / List      |
|    | PR+         |    | CH+ / Page+       |
|    | Vol-        |    | Vol-              |
|    | PR-         |    | CH- / Page-       |
|    | 1           |    | 1                 |
|    | 2           |    | 2                 |
|    | 3           |    | 3                 |
|    | 4           |    | 4                 |
|   | 5           |   | 5                 |
|  | 6           |  | 6                 |
|  | 7           |  | 7                 |
|  | 8           |  | 8                 |
|  | 9           |  | 9                 |
|  | -/-         |  | Guide / EPG / -/- |
|  | 0           |  | 0                 |



