




































































| Original | Replacement | Original | Replacement |
|---|---|---|--|
|  |  Power |  |  4 |
|  |  Red / Netflix / Search |  |  5 |
|  |  Green / APP / Repeat |  |  6 |
|  |  Yellow / YouTube / Repeat |  |  7 |
|  |  Blue / Prime Video / Random |  |  8 |
|  |  Exit / Cancel / Clear |  |  9 |
|  |  Sleep / Timer |  |  Picture / Format |
|  |  Stop / Hold |  |  0 |
|  |  Smart / List |  |  Shift + Guide / EPG / -/-- |
|  |  Text / Goto |  |  Vol- |
|  |  Setup / OPT / |  |  Vol+ |
|  |  Menu / Home |  |  Mute / Dimmer |
|  |  Shift + Info / Angle |  |  CH- / Page- |
|  |  Guide / EPG / -/-- |  |  CH+ / Page+ |
|  |  1 |  |  Info / Angle |
|  |  2 |  |  TV/Radio / |
|  |  3 |  |  AV / Input / RDS |



