



| Original |            | Replacement |       | Original |           | Replacement |        |
|----------|------------|-------------|-------|----------|-----------|-------------|--------|
|          | Power      |             | Power |          | 0         |             | 0      |
|          | Up         |             | Up    |          | Exit/-/-- |             | Exit   |
|          | Down       |             | Down  |          | PP        |             | Pre Ch |
|          | Right      |             | Right |          | Swap/P<P  |             | Smart  |
|          | Left       |             | Left  |          | CH+       |             | Ch +   |
|          | OK/Select  |             | Ok    |          | CH-       |             | Ch -   |
|          | M          |             | Menu  |          | Vol+      |             | Vol +  |
|          | [ i ]/Info |             | Info  |          | Vol-      |             | Vol -  |
|          | 1          |             | 1     |          | Mute      |             | Mute   |
|          | 2          |             | 2     |          | I-II      |             | Dual   |
|          | 3          |             | 3     |          | Tv/DTV    |             | TV/R   |
|          | 4          |             | 4     |          | AV/Source |             | AV     |
|          | 5          |             | 5     |          | Red/↑     |             | Red    |
|          | 6          |             | 6     |          | Green/↓   |             | Green  |
|          | 7          |             | 7     |          | Yellow    |             | Yellow |
|          | 8          |             | 8     |          | Blue      |             | Blue   |
|          | 9          |             | 9     |          | [≡]       |             | Text   |



