



















































Original	Replacement
 Power	 Power
 Ambilight	 Format
 List	 List
 */Settings	 Menu
 TV Guide	 Guide
 Voice	 Pre Ch
 Top Pics	 3D
 Sources	 AV
 Folders	 TV/R
 Exit/TV	 Exit
 Info	 Info
 Options	 Options
 Back	 Back
 Home	 Smart
 OK	 Ok
 Up	 Up
 Down	 Down

Original	Replacement
 Right	 Right
 Left	 Left
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Netflix	 Media
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5





	Original	Replacement		Original	Replacement
	6				
	7				
	8				
	9				
	0				
	Text				
	Subtitle				
	Stop				
	Pause				
	Rec				
	<<				
	>>				
	Play				

