



































































































| Original                                                                            |          | Replacement                                                                         |              | Original                                                                              |            | Replacement                                                                           |       |
|-------------------------------------------------------------------------------------|----------|-------------------------------------------------------------------------------------|--------------|---------------------------------------------------------------------------------------|------------|---------------------------------------------------------------------------------------|-------|
|    | Power    |    | Power        |    | Xacti Menu |    | Blue  |
|    | Eco      |   | Shift + 3D   |    | 1          |    | 1     |
|    | Audio    |    | Dual         |    | 2          |    | 2     |
|    | On Timer |    | Text         |    | 3          |    | 3     |
|    | Caption  |    | Subt         |    | 4          |    | 4     |
|    | Reset    |    | 3D           |    | 5          |    | 5     |
|    | Sleep    |    | Sleep        |    | 6          |    | 6     |
|    | Picture  |    | Format       |    | 7          |    | 7     |
|    | Sound    |   | Shift + Dual |    | 8          |    | 8     |
|   | Play     |   | Play         |   | 9          |   | 9     |
|  | Pause    |  | Pause        |  | 0          |  | 0     |
|  | Stop     |  | Stop         |  | --/Sub CH  |  | Guide |
|  | <<       |  | <<           |  | Input      |  | AV    |
|  | >>       |  | >>           |  | Vol+       |  | Vol + |
|  | W        |  | Red          |  | Vol-       |  | Vol - |
|  | T        |  | Green        |  | Mute       |  | Mute  |
|  | Camera   |  | Yellow       |  | CH+        |  | Ch +  |





|                                                                                     | Original  | Replacement                                                                               | Original | Replacement |
|-------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------------------------------|----------|-------------|
|    | CH-       |  Ch -    |          |             |
|    | Recall    |  Pre Ch  |          |             |
|    | DYN Vol   |  Smart   |          |             |
|    | USB       |  Media   |          |             |
|    | Pix Shape |  Options |          |             |
|    | Menu      |  Menu    |          |             |
|    | Help      |  D. Menu |          |             |
|    | Info      |  Info    |          |             |
|    | Exit      |  Exit    |          |             |
|    | Up        |  Up      |          |             |
|    | Down      |  Down    |          |             |
|   | Right     |  Right  |          |             |
|  | Left      |  Left  |          |             |
|  | Enter     |  Ok    |          |             |
|                                                                                     |           |                                                                                           |          |             |
|                                                                                     |           |                                                                                           |          |             |
|                                                                                     |           |                                                                                           |          |             |
|                                                                                     |           |                                                                                           |          |             |

