



































Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow
 Play	 Play	 Blue	 Blue
 Stop	 Stop	 CH+	 Ch +
 Pause	 Pause	 CH-	 Ch -
 <<<	 <<<	 Vol+	 Vol +
 >>>	 >>>	 Vol-	 Vol -
 I<<<	 I<<<	 MENU	 Menu
 >>>I	 >>>I	 SOURCE	 AV
 TV/TXT	 REPEAT TEXT	 DVB	 Smart
 Cancel	 RETURN BACK	 EXIT	 Exit
 REVEAL	 ZOOM	 OK	 Ok
 HOLD	 APP MEDIA	 Up	 Up
 SIZE	 ECO 3D	 Down	 Down
 SUBPAGE	 E-MANUAL D.MENU	 Right	 Right
 INDEX	 DISC NAV LIST	 Left	 Left
 Red	 A	 1	 1
 Green	 B	 2	 2





Original	Replacement	Original	Replacement
 3	 3	 3	 3
 4	 4	 4	 4
 5	 5	 5	 5
 6	 6	 6	 6
 7	 7	 7	 7
 8	 8	 8	 8
 9	 9	 9	 9
 0	 0	 0	 0
 -/--	 SHIFT + -/--	 SHIFT + -/--	 Guide
 Recall	 Pre Ch	 Pre Ch	 Pre Ch
 Picture	 Shift + Format	 Shift + Format	 Shift + Format
 Sound	 Shift + Dual	 Shift + Dual	 Shift + Dual
 Nicam/A2	 Options	 Options	 Options
 Mute	 Mute	 Mute	 Mute
 Sleep	 Sleep	 Sleep	 Sleep
 Tv/Radio	 TV/R	 TV/R	 TV/R
 FAV	 Shift + Pre Ch	 Shift + Pre Ch	 Shift + Pre Ch

Original	Replacement	Original	Replacement
 FAV+	 Shift + Ch +	 FAV+	 Shift + Ch +
 FAV-	 Shift + Ch -	 FAV-	 Shift + Ch -
 Pic Format	 Format	 Pic Format	 Format
 Subtitle	 Subt	 Subtitle	 Subt
 Text	 Shift + Text	 Text	 Shift + Text
 Display	 Info	 Display	 Info
 Language	 Dual	 Language	 Dual
 EPG	 Guide	 EPG	 Guide

