







































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue	 Blue
 Tv/Radio	 TV/R	 OK	 Ok
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 Mute	 Mute
 0	 0	 Teletext	 Text
 Menu	 Menu	 EPG	 Guide
 Exit	 Exit	 Info	 Info
 Red	 Red	 FAV	 Pre Ch
 Green	 Green	 Subtitle	 Subt
 Yellow	 Yellow	 Lang	 Dual



