






































































Original		Replacement		Original		Replacement	
	Power		Power		P+		Ch +
	Mute		Mute		P-		Ch -
	TV		Smart		Vol+		Vol +
	Pause		Pause		Vol-		Vol -
	Radio		TV/R		1		1
	AV		AV		2		2
	Text		Text		3		3
	Swap		Back		4		4
	List		List		5		5
	Exit		Exit		6		6
	Info		Info		7		7
	Menu		Menu		8		8
	Up		Up		9		9
	Down		Down		0		0
	Right		Right		EPG		Guide
	Left		Left		FAV		Pre Ch
	OK		Ok		Red		Red



