


























































Original		Replacement		Original		Replacement	
	Power		Power		EPG		Guide
	Mute		Mute		Sat		Smart
	1		1		Exit		Exit
	2		2		Up		Up
	3		3		Prog +		Ch +
	4		4		Down		Down
	5		5		Prog -		Ch -
	6		6		Right		Right
	7		7		Vol +		Vol +
	8		8		Left		Left
	9		9		Vol -		Vol -
	0		0		Ok		Ok
	Pause		Pause		TV / Radio		TV/R
	Recall		Back		Zoom		Eject
	Fav		Pre Ch		Page -		<<
	Menu		Menu		Page -		I<<
	i		Info		Help		D. Menu





Original	Replacement	Original	Replacement
 F1	 Options		
 Page +	 >>		
 Page +	 >>		
 UHF	 Format		
 P/N	 3D		
 TV/SAT	 Media		
 Subtitles	 Subt		
 Audio	 Dual		
 Red / Audio	 Red		
 Green / Mosaic	 Green		
 Yellow / Clock	 Yellow		
 Blue / Text	 Blue		
 Text	 Text		

