


















































































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 AV/Source	 AV / Input / RDS
 0	 0
 Exit/--	  +  Shift + Guide / EPG / --
 Exit/--	 Exit / Cancel / Clear
 P<P/SWAP	  Fav / Marker / PC
 Info	  Info / Angle
 PP	  Back / Return

Original	Replacement
 I/II	  Audio / Lang I/II
 Ok/Select	 OK
 Up	 Up
 Left	 Left
 Right	 Right
 Down	 Down
 Menu	  Menu / Home
 TV/DTV	  TV/Radio /
 CH+ / Page+	  CH+ / Page+
 Vol+	  Vol+
 CH- / Page-	  CH- / Page-
 Mute	  Mute / Dimmer
 Vol-	  Vol-
 Red/↑	  +  Shift + CH+ /
 Red/↑	  Red / Netflix / Search
 Green/↓	  +  Shift + CH- /
 Green/↓	  Green / APP / Repeat





Original		Replacement		Original	Replacement
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	[=]		Text / Goto		
	[=0]		Sleep / Timer		
	[=+]/[+]		Stop / Hold		
	[=x]/[· ·]		D.Menu / Top		
	[/=]/[*]		Setup / OPT /		
	[=◆]/[X]/Wide		Picture / Format		
	[=◆]/[X]/Wide		Zoom / Size		
	[=?]		Smart / List		
	[=i]/Guide		Guide / EPG / -/--		

