













Original	Replacement
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TV/R
	Back
	Guide
	Menu
	Info

Original	Replacement
	Exit
	Up
	Down
	Ok
	Right
	Left
	Vol +
	Vol -
	Ch +
	Ch -
	Pause
	3D
	Pre Ch
	Smart
	Format
	AV
	Red





Original	Replacement
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Audio	 Dual
 TXT	 Text
 [...]	 Subt
 Audio L/R	 +  Shift + Dual

Original	Replacement

