



| Original     | Replacement       |
|--------------|-------------------|
| Power        | Power             |
| Drive Select | AV / Input / RDS  |
| 1            | 1                 |
| 2            | 2                 |
| 3            | 3                 |
| 4            | 4                 |
| 5            | 5                 |
| 6            | 6                 |
| 7            | 7                 |
| 8            | 8                 |
| 9            | 9                 |
| 0            | 0                 |
| CH/Page+     | CH+ / Page+       |
| Last View    | Fav / Marker / PC |
| CH/Page-     | CH- / Page-       |
| Radio/Tv     | TV/Radio /        |
| Internet     | Smart / List      |

| Original              | Replacement                 |
|-----------------------|-----------------------------|
| Skype                 | Shift + Smart / List        |
| I<< Skip              | I<< / Preset-               |
| Skip >>I              | >>I / Preset+               |
| Stop                  | Stop / Hold                 |
| Play                  | Play / Slow                 |
| <<< / Tune-           | <<< / Tune-                 |
| Option                | Shift + Setup / OPT / Tools |
| >>> / Tune+           | >>> / Tune+                 |
| Pause / Step / Freeze | Pause / Step / Freeze       |
| Return                | Back / Return               |
| i/Status              | Info / Angle                |
| X/Exit                | Exit / Cancel / Clear       |
| Guide                 | Guide / EPG / -/-           |
| Up                    | Up                          |
| Pop-Up menu/Direct    | D.Menu / Top                |
| Down                  | Down                        |
| Right                 | Right                       |





| Original |               | Replacement |                             | Original |                  | Replacement |                          |
|----------|---------------|-------------|-----------------------------|----------|------------------|-------------|--------------------------|
|          | Left          |             | Left                        |          | CH- Tv           |             | Shift + CH- /            |
|          | Function Menu |             | Menu / Home                 |          | CH+ Tv           |             | Shift + CH+ /            |
|          | OK            |             | OK                          |          | Vol- Tv          |             | Vol-                     |
|          | Red           |             | Red / Netflix / Search      |          | Vol+ Tv          |             | Vol+                     |
|          | Green         |             | Green / APP / Repeat        |          | Power Tv         |             | Shift + Power            |
|          | Yellow        |             | Yellow / YouTube / Repeat   |          | AV Input Tv      |             | Shift + AV / Input / RDS |
|          | Blue          |             | Blue / Prime Video / Random |          | Manual Skip +60s |             | Shift + Right            |
|          | Rec           |             | Rec / Rec Mode              |          | Manual Skip -10s |             | Shift + Left             |
|          | Audio         |             | Audio / Lang I/II           |          |                  |             |                          |
|          | Text          |             | Text / Goto                 |          |                  |             |                          |
|          | STTL          |             | Subtitle / EQ               |          |                  |             |                          |
|          | Display       |             | Display / Media             |          |                  |             |                          |
|          | Chapter       |             | Zoom / Size                 |          |                  |             |                          |
|          | Setup         |             | Setup / OPT /               |          |                  |             |                          |
|          | Prog/Check    |             | Shift + TV/Radio / Program  |          |                  |             |                          |
|          | Time Slip     |             | Picture / Format            |          |                  |             |                          |
|          | DEL           |             | Sleep / Timer               |          |                  |             |                          |

