





































































Original	Replacement	Original	Replacement
 Power	 Power	 Tv Pre-CH	 Back
 Tv Power	 Shift + Power	 Dimmer	 0
 Source	 AV	 I<<	 I<<
 Auto Power	 Sleep	 Stop	 Stop
 Speaker	 Pre Ch	 Play	 Play
 Tv Source	 Shift + AV	 Pause	 Pause
 Repeat	 Text	 >>I	 >>I
 Any net	 Media	 Sound Effect	 Menu
 Soundshare	 Dual	 Smart Volume	 Smart
 Tv Vol+	 Shift + Vol +	 3D Sound Plus	 3D
 Tv Vol-	 Shift + Vol -	 DRC	 Subt
 Tv CH+	 Ch +	 Right S/W Level	 Right
 Tv CH-	 Ch -	 Left S/W Level	 Left
 Audio Sync+	 3	 Vol+	 Vol +
 Audio Sync-	 6	 Vol-	 Vol -
 Tv Mute	 Shift + Mute	 Mute	 Mute
 Tv Info	 Info		

