







































































Original	Replacement	Original	Replacement
 Power	 Power	 Mute	 Mute
 Source	 AV	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Menu	 Menu
 3	 3	 Q.Menu	 D. Menu
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 OK	 Ok
 [TV]	 TV/R	 i	 Info
 ↔	 Pre Ch	 [>]	 Options
 Internet	 Smart	 EPG	 Guide
 Vol+	 Vol +	 *1	 Format
 Vol-	 Vol -	 *2	 3D





Original	Replacement	Original	Replacement
TXT	Text		
Lang.	Dual		
Subt.	Subt		
[+]	Eject		
<<<	<<<		
Pause	Pause		
>>>	>>>		
Rec	Rec		
Play	Play		
Stop	Stop		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		

