







































































Original		Replacement		Original		Replacement	
	Power		Power		List		Smart / List
	Energy/Saving		Eject / Surround		Settings		Menu / Home
	TV/Radio		TV/Radio /		Q.View		Display / Media
	Guide		Guide / EPG / -/--		Q.Menu		D.Menu / Top
	Info		Info / Angle		Back		Back / Return
	Ratio		Picture / Format		Exit		Exit / Cancel / Clear
	Input		AV / Input / RDS		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		OK
	5		5		Vol+		Vol+
	6		6		Vol-		Vol-
	7		7		Mute		Mute / Dimmer
	8		8		FAV		Fav / Marker / PC
	9		9		AD		Audio / Lang I/II
	0		0		P+		CH+ / Page+





	Original	Replacement	Original	Replacement
	P-	CH- / Page-		
	Red	Red / Netflix / Search		
	Green	Green / APP / Repeat		
	Yellow	Yellow / YouTube / Repeat		
	Blue	Blue / Prime Video / Random		
	Stop	Stop / Hold		
	Play	Play / Slow		
	Pause	Pause / Step / Freeze		
	Subtitle	Subtitle / EQ		
	<<	<< / Tune-		
	>>	>> / Tune+		
	Text	Text / Goto		
	T.Opt	Setup / OPT /		

