







































































Original	Replacement
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/-	 GUIDE
 S	 PRE-CH
 <<	 <<
 ■	 ■
 ▶	 ▶

Original	Replacement
 >>	 >>
 V.MENU	 D. Menu
 MUTE	 MUTE
 P+	 Ch +
 P-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 MENU	 MENU
 DISPLAY	 INFO
 P.STD	 3D
 REC	 REC
 EJECT	 EJECT
 P/S&LNA	 Pause





Original	Replacement	Original	Replacement
Crystal PB	TV/R		
TRK up	>>I		
TRK Down	I<<		
Index	List		
Memory	Ok		
Sleep	Sleep		
Lang.Sel	Dual		
Clear	Exit		

