




Original	Replacement	Original	Replacement
	Power		Red
	TXT		Green
	EPG		Yellow
	Input		Blue
	Menu		Vol +
	Lang		Vol -
	Subt		Mute
	i		[+]
	Exit		P+
	Q.Menu		P-
	Back		1
	Up		2
	Down		3
	Right		4
	Left		5
	OK		6
			7



