



| Original  | Replacement   | Original  | Replacement |
|---|---------------|---|-------------|
|    | Power         |    | Power       |
|    | Open/Close    |    | Eject       |
|    | Home          |    | Smart       |
|    | Menu/Disc     |    | Menu        |
|    | Options       |    | Options     |
|    | Back          |    | Back        |
|    | Stop          |    | Stop        |
|    | Play          |    | Play        |
|    | Pause         |    | Pause       |
|    | I<            |    | I<<         |
|  | >I            |  | >>I         |
|  | >>            |  | >>          |
|  | <<            |  | <<          |
|  | Up            |  | Up          |
|  | Down          |  | Down        |
|  | Right         |  | Right       |
|  | Left          |  | Left        |
|  | OK            |  | Ok          |
|  | Subtitle      |  | Subt        |
|  | Goto          |  | Guide       |
|  | Audio         |  | Dual        |
|  | [<>]          |  | Format      |
|  | Volume        |  | Media       |
|  | Repeat/Repeat |  | Text        |

