























































Original		Replacement		Original		Replacement	
	Power		Power		OK		Ok
	Mute		Mute		Down		Down
	1		1		Left		Left
	2		2		Right		Right
	3		3		Menu		Menu
	4		4		Return		Back
	5		5		Tv/Radio		TV/R
	6		6		O)/A-B		Dual
	7		7		List		List
	8		8				
	9		9				
	0		0				
	Vol+		Vol +				
	Vol-		Vol -				
	Prog+		Ch +				
	Prog-		Ch -				
	Up		Up				

