






































































| Original | Replacement | Original | Replacement |
|---|---------------|---|-----------------------|
|  | Power |  | Power |
|  | i |  | Info / Angle |
|  | Analog Menu |  | Menu / Home |
|  | Digital Menu |  | D.Menu / Top |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | Input Select |  | AV / Input / RDS |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | TV/DVB-T |  | Display / Media |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | Guide (EPG) |  | Guide / EPG / -/- |
|  | Timer |  | Sleep / Timer |
|  | 0 |  | 0 |
|  | Mute |  | Mute / Dimmer |
|  | Exit |  | Exit / Cancel / Clear |
|  | Vol+ |  | Vol+ |
|  | Up |  | Up |
|  | P+ |  | CH+ / Page+ |
|  | Left |  | Left |
|  | Enter/CH List |  | OK |
|  | Enter/CH List |  | Smart / List |
|  | Right |  | Right |
|  | Vol- |  | Vol- |
|  | Down |  | Down |
|  | P- |  | CH- / Page- |
|  | TV/Radio |  | TV/Radio / |
|  | [≡] |  | Text / Goto |
|  | [≡o] [≡o]/P↔P |  | Back / Return |
|  | Picture Size |  | Picture / Format |





| Original | Replacement | Original | Replacement |
|---------------|-----------------------------|----------|-------------|
| [...] | Subtitle / EQ | | |
| Freeze / [=+] | Pause / Step / Freeze | | |
| [=◇] | Zoom / Size | | |
| [=?] | Setup / OPT / | | |
| Audio I/II | Audio / Lang I/II | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

