























































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 i	 Info / Angle	 Mute	 Mute / Dimmer
 Analog Menu	 Menu / Home	 Exit	 Exit / Cancel / Clear
 Digital Menu	 D.Menu / Top	 Vol+	 Vol+
 1	 1	 Up	 Up
 2	 2	 P+	 CH+ / Page+
 3	 3	 Left	 Left
 Input Select	 AV / Input / RDS	 Enter/CH List	 OK
 4	 4	 Enter/CH List	 Smart / List
 5	 5	 Right	 Right
 6	 6	 Vol-	 Vol-
 TV/DVB-T	 Display / Media	 Down	 Down
 7	 7	 P-	 CH- / Page-
 8	 8	 TV/Radio	 TV/Radio /
 9	 9	 [≡]	 Text / Goto
 Guide (EPG)	 Guide / EPG / -/--	 [=o] [=o]/P<->P	 Back / Return
 Timer	 Sleep / Timer	 Picture Size	 Picture / Format





Original	Replacement	Original	Replacement
 [...]	 Subtitle / EQ		
 Freeze / [=+]	 Pause / Step / Freeze		
 [=◇]	 Zoom / Size		
 [=?]	 Setup / OPT /		
 Audio I/II	 Audio / Lang I/II		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		

Original	Replacement	Original	Replacement

