







































| Original  | Replacement  |
|---|--|
|  Power         |  Power  |
|  Mute          |  Mute   |
|  Eject / Nicam |  Eject  |
|  Recall / Goto |  Pre Ch |
|  1             |  1      |
|  2             |  2      |
|  3             |  3      |
|  4             |  4      |
|  5             |  5      |
|  6             |  6      |
|  7            |  7     |
|  8           |  8    |
|  9           |  9    |
|  0           |  0    |
|  TV Menu     |  Menu |
|  Source      |  AV   |
|  Up          |  Up   |

| Original  | Replacement  |
|---|--|
|  Right         |  Right          |
|  Down          |  Down           |
|  Left          |  Left           |
|  Enter         |  Ok             |
|  DVD/DVB Menu  |  D. Menu        |
|  Exit          |  Exit           |
|  Vol +         |  Vol +          |
|  Vol -         |  Vol -          |
|  Sound         |  Shift + Dual   |
|  PIC           |  Shift + Format |
|  CH +         |  Ch +          |
|  CH -        |  Ch -         |
|  Sleep       |  Sleep        |
|  Aspect      |  Format       |
|  Rad / DVD   |  Options      |
|  Recall / TV |  Back         |
|  Text        |  Text         |





| Original  | Replacement  |
|---|--|
|  Play/Pause / Info |  Info           |
|  Play/Pause / Info |  Play           |
|  Play/Pause / Info |  Pause          |
|  Stop / FAV        |  Shift + Pre Ch |
|  Stop / FAV        |  Stop           |
|  EPG               |  Guide          |
|  Red / DVD/USB     |  Red            |
|  Green / Title     |  Green          |
|  Yellow / PBC      |  Yellow         |
|  Blue / Angle      |  Blue           |
|  << / Reveal      |  <<            |
|  >> / Hold       |  >>           |
|  I<< / List      |  I<<          |
|  >>I / Index     |  >>I          |
|  Subpage         |  Media        |
|  Display         |  Shift + Info |
|  Audio           |  Dual         |

| Original   | Replacement  |
|--|--|
|  Subtitle |  Subt |

