





































| Original | Replacement |
|---|--|
|  |  Power |
|  |  Mute / Dimmer |
|  |  Play / Slow |
|  |  Stop / Hold |
|  |  Rec / Rec Mode |
|  |  << / Tune- |
|  |  >> / Tune+ |
|  |  I<< / Preset- |
|  |  >>I / Preset+ |
|  |  Subtitle / EQ |
|  |  Picture / Format |
|  |  Menu / Home |
|  |  Up |
|  |  Info / Angle |
|  |  Left |
|  |  OK |
|  |  Right |

| Original | Replacement |
|---|---|
|  |  Down |
|  |  Back / Return |
|  |  Vol+ |
|  |  Smart / List |
|  |  CH+ / Page+ |
|  |  Vol- |
|  |  CH- / Page- |
|  |  1 |
|  |  2 |
|  |  3 |
|  |  4 |
|  |  5 |
|  |  6 |
|  |  7 |
|  |  8 |
|  |  9 |
|  |  Guide / EPG / -/- |





| Original | Replacement | Original | Replacement |
|--------------|-----------------------------|----------|-------------|
| 0 | 0 | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| Play / Pause | Shift + Play / | | |
| C | Shift + Subtitle / EQ | | |
| Retour | Shift + Back / Return | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

