















































| Original     | Replacement   | Original   | Replacement   |
|--------------|---|------------|---|
| On/Off       |  Power                 | Menu       |  Menu / Home           |
| Audio Off    |  Mute / Dimmer         | Menu Up    |  Up                    |
| Play         |  Play / Slow           | Auto/Track |  Info / Angle          |
| Pause        |  Pause / Step / Freeze | Menu Left  |  Left                  |
| Stop         |  Stop / Hold           | OK Enter   |  OK                    |
| Record       |  Rec / Rec Mode        | Menu Right |  Right                 |
| Rewind       |  << / Tune-            | C/CH       |  Exit / Cancel / Clear |
| F.Forward    |  >> / Tune+            | Menu Down  |  Down                  |
| Prev.        |  I<< / Preset-         | Return     |  Back / Return         |
| Next         |  >>I / Preset+         | Volume+    |  Vol+                  |
| Title        |  Sound / Title        | DVD/TV     |  Smart / List         |
| Subt.        |  Subtitle / EQ       | Slow Up    |  CH+ / Page+         |
| Open/Close   |  Eject / Surround    | Volume-    |  Vol-                |
| Zoom         |  Zoom / Size         | Display    |  Display / Media     |
| Progr.       |  TV/Radio /          | Slow Down  |  CH- / Page-         |
| Top Menu     |  D.Menu / Top        | 1          |  1                   |
| Input Source |  AV / Input / RDS    | 2          |  2                   |



| Original     | Replacement   | Original | Replacement |
|--------------|---|----------|-------------|
| 3            |  3                           |          |             |
| 4            |  4                           |          |             |
| 5            |  5                           |          |             |
| 6            |  6                           |          |             |
| 7            |  7                           |          |             |
| 8            |  8                           |          |             |
| 9            |  9                           |          |             |
| +10          |  Guide / EPG / -/--          |          |             |
| 0            |  0                           |          |             |
| Mark         |  Fav / Marker / PC           |          |             |
| Repeat/1/All |  Green / APP / Repeat      |          |             |
| Rep/A-B      |  Yellow / YouTube / Repeat |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |
|              |   |          |             |

