




















































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	DTV / ATV	 + 	Shift + TV/R
	Recall		Back
	V +		Vol +
	V -		Vol -
	Rec		Rec

Original	Replacement	Original	Replacement
	Rec List		List
	CH +		Ch +
	CH -		Ch -
	Menu		Menu
	Source		AV
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	Enter		Ok
	Exit		Exit
	Display		Info
	P.Mode	 + 	Shift + Format
	S.Mode		Dual
	Sleep		Sleep
	Fav / List		Pre Ch
	MTS	 + 	Shift + Dual





Original	Replacement
Freeze	+  Shift + Pause
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
<< / Guide	<<
<< / Guide	Guide
Play/Pause / Timeshift	Play
Play/Pause / Timeshift	Pause
>> / Aspect	>>
>> / Aspect	Format
I<< / Cancel	I<<
I<< / Cancel	+  Shift + Exit
>>I / Sub.Pg	>>I
>>I / Sub.Pg	+  Shift + Subt
Stop / Index	Stop
Stop / Index	+  Shift + Info

Original	Replacement
TV / Radio	TV/R
Subtitle	Subt
Reveal	Options
Size	Eject
Hold	+  Shift + Stop
Text	Text

