




Original		Replacement		Original		Replacement	
	Power		Power		Recall / Mouse		Back
	Mute		Mute		FAV		Pre Ch
	P.Mode		Shift + Format		Red		Red
	S.Mode		Dual		Settings		Options
	Nicam / A2		Shift + Dual		Home		Smart
	Sleep		Sleep		Green		Green
	1		1		Yellow		Yellow
	2		2		Blue		Blue
	3		3		Source		AV
	4		4		Info		Info
	5		5		Up		Up
	6		6		Right		Right
	7		7		Down		Down
	8		8		Left		Left
	9		9		OK		Ok
	0		0		Menu		Menu
	-/--		Guide		Exit		Exit



