



































| Original   | Replacement  |
|--|--|
|  Power      |  Power    |
|  TV / Video |  AV       |
|  1          |  1        |
|  2          |  2        |
|  3          |  3        |
|  4          |  4        |
|  5          |  5        |
|  6          |  6        |
|  7          |  7        |
|  8          |  8        |
|  9         |  9       |
|  0        |  0      |
|  /--      |  GUIDE  |
|  Quick    |  Pre Ch |
|  Mute     |  Mute   |
|  Sleep    |  Sleep  |
|  Skip     |  Exit   |

| Original  | Replacement  |
|---|--|
|  Display       |  Info             |
|  Up / Prog +   |  Ch +             |
|  Up / Prog +   |  Up               |
|  Down / Prog - |  Ch -             |
|  Down / Prog - |  Down             |
|  Right / Vol + |  Vol +            |
|  Right / Vol + |  Right            |
|  Left / Vol -  |  Vol -            |
|  Left / Vol -  |  Left             |
|  Menu          |  Menu             |
|  Menu         |  Ok              |
|  P-STD       |  Shift + Format |
|  S-STD       |  Dual           |
|  PC Auto ADJ |  Smart          |
|  PC / TV/PC  |  Media          |
|  M / S       |  TV/R           |
|  Surround    |  Shift + Dual   |



