






















































Original	Replacement
 Input	 AV / Input / RDS
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Pro. List	 Smart / List
 0	 0
 Last	 Back / Return
 Info	 Info / Angle
 Up	 Up
 Menu	 Menu / Home

Original	Replacement
 Left	 Left
 OK	 OK
 Right	 Right
 EPG	 Guide / EPG / -/--
 Down	 Down
 Text	 Text / Goto
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 Vol-	 Vol-
 I/II	 Display / Media
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 [≡i]/Index	 Shift + AV / Input / RDS





Original	Replacement
 [/≡]/Mix	 Shift + Text /
 [≡♦]/Size	 Zoom / Size
 [≡B]/Subtitle	 Subtitle / EQ
 [≡+]/Hold	 Stop / Hold
 [≡?]/Reveal	 Shift + Info / Angle
 (·)/Sound	 Sound / Title
 []/Pict	 Picture / Format
 ♥/FAV	 Fav / Marker / PC
 */Freeze	 Setup / OPT /
 Sleep	 Sleep / Timer
 [<>]/Aspect	 D.Menu / Top

Original	Replacement

