





































Original	Replacement
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Recall	 Pre Ch
 SS-Titre	 Subt
 Accueil	 D. Menu
 YouTube	 Media

Original	Replacement
 Netflix	 Smart
 Reg. Rapide	 3D
 Menu	 Menu
 Retour/Guide	 Guide
 Sortie	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK/Liste	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute





Original		Replacement		Original	Replacement
	CH+		Ch +		
	CH-		Ch -		
	I/II Audio/Lang		Dual		
	Play		Play		
	Pause/Index		Pause		
	Stop/Garde		Stop		
	Rec/Mix		Rec		
	I<<		I<<		
	Texte		Text		
	>>I		>>I		
	Taille		Format		
	<</Revele		<<		
	>>/Annule		>>		
	Heure/Pg Ht		List		
	SS-Code/Pg Bs		Sleep		

