






















































Original	Replacement	Original	Replacement
 Power	 Power	 Smart Picture	 Format
 Sleep	 Sleep	 Menu	 Menu
 Exit	 Exit	 Text / OK	 Ok
 I-II	 Dual	 Text / OK	 Text
 I.S.	 Smart	 Up	 Up
 [i+]	 Info	 Left	 Left
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Vol +	 Vol +
 4	 4	 Vol -	 Vol -
 5	 5	 Mute	 Mute
 6	 6	 P +	 Ch +
 7	 7	 P -	 Ch -
 8	 8	 Red / Rec	 Red
 9	 9	 Red / Rec	 Rec
 0	 0	 Green / <<	 Green
 Smart Audio	 Shift + Dual	 Green / <<	 <<





Original	Replacement	Original	Replacement
 Yellow / Stop	 Yellow		
 Yellow / Stop	 Stop		
 Blue / Play	 Blue		
 Blue / Play	 Play		
 [X]	 SHIFT +  CLEAR EXIT Exit		
 [♦] / ⊕	 3D		
 [□] / >>	 SHIFT +  Stop		
 [□] / >>	 >>		
 [/≡]	 SHIFT +  REPEAT TEXT Text		
 [?]	 SEARCH TV/R		
 [≡]	 GUIDE		

